


Instructions

SAVE THESE INSTRUCTIONS

INSTALLATION

1. If required, the swivel lamps can be adjusted. The rotation of the heads is limited. Try not to extend beyond the angle shown (Fig.2) to avoid internal mechanical damage. To adjust, loosen screws, rotate up/down and/or left/right as the arrow indicates in (Fig.1) and retighten screws.
2. This unit can be mounted on a wall, ceiling, or placed on a shelf. To mount on a wall or ceiling utilize the keyhole slots on back plate. Place the 2 screws (with anchors) provided in the wall (template below). Do not tighten the screws in completely. Place the light in desired position by lining up the screws with the hanging holes on the back of the unit.
3. Connect the adapter to the light and then plug the adapter into a standard AC outlet to charge the battery. The battery requires 48-72 hours to reach a full charge and provide maximum service. The "CHARGE" LED will stay lit while the battery is charging. You may test the function by pressing the TEST button on the side panel (unit must be plugged in and in POWER FAILURE MODE).



To set the unit to POWER FAILURE MODE:

1. Chose 1 or 2 LIGHTS.
2. Set mode to OFF
3. PLUG IN THE UNIT

Other Set up / User options:

For use as a portable flashlight or work-light:

1. Set lights to 1 or 2.
2. Unplug the unit.
3. When no longer needed, plug in again. Ensure that it is set back into **Power Failure** mode.

For use as a night or guide light using the built-in PHOTOCELL. (A photocell controls the operation of the light by turning on only when the area around the light is dark). (Unit is plugged in). The light in this mode is softer than in power failure mode.

1. Set LIGHT control **OFF**.
2. Set MODE to **AUTO**.

In the above set-up, the light(s) will automatically come on in darkness and turn off when there is enough light. During a power failure, or unplugged, the unit functions in the same way. The light (s) will only come on if dark. If brighter light is required during a loss of power, switch LIGHT set up to **2 lights**.

For use as a soft accent (night light) without Photocell: (Plugged in). In this mode the light(s) will be on during light and dark. It is very low intensity.

1. Set LIGHTS to OFF
2. Set MODE to ON

If power failure occurs in this mode, the intensity remains the same. If more light is needed, switch the **LIGHT** function to **2**.

TESTING

To Test, Depress and hold the "TEST" switch located on the right side of the unit (Settings must be in **POWER FAILURE** mode). One or two of the lamps should come on depending on your setting. When the button is released, the light(s) will go off. The TEST will only function when unit is plugged in.

